

Time of Flight Pad

(Order Code: TOF-VPL)



The Time of Flight Pad is an accessory timing device for use with the Go Direct® Projectile Launcher (GDX-PL) or the Vernier Projectile Launcher (VPL). The standard experiment performed with the Time of Flight Pad is the measurement of the time interval taken by a projectile from the moment of launch to the moment of landing—in other words, the time of flight.

In addition to working with a projectile launcher, the Time of Flight Pad can be used daisy-chained to a Vernier Photogate (VPG-BTD) or Go Direct Photogate (GDX-VPG). Connecting to a Go Direct Photogate requires a separate cable (TOF-CB-GDX) not included with the Time of Flight Pad. You can also connect the Time of Flight Pad directly to a digital port on a supported interface for using the pad as an independent sensor. In this situation, the Time of Flight Pad is identified by the software as a photogate.

Note: Vernier products are designed for educational use. Our products are not designed nor recommended for any industrial, medical, or commercial process such as life support, patient diagnosis, control of a manufacturing process, or industrial testing of any kind.

What's Included

- Time of Flight Pad
- 4 meter projectile launcher cable
- 1.2 meter photogate cable

Compatible Software

See www.vernier.com/manuals/tof-vpl for a list of software compatible with the Time of Flight Pad.

When the Time of Flight Pad is used with a projectile launcher or daisy-chained to a photogate, the compatible software depends on sensor and interface to which it is connected.

- For Go Direct Projectile Launcher, see www.vernier.com/manuals/gdx-pl
- For Vernier Projectile Launcher, see www.vernier.com/manuals/vpl
- For Go Direct Photogate, see www.vernier.com/manuals/gdx-vpg
- For Vernier Photogate, see www.vernier.com/manuals/vpg-btd

Getting Started

Follow these steps when using the Time of Flight Pad with a projectile launcher.

1. Connect the included 4 meter projectile launcher cable to the Time of Flight Pad.

2. Connect the other end of the cable to the Accessories (or Ext. Switch) port on the projectile launcher.
3. Follow the instructions for connecting a projectile launcher:
 - For the Go Direct Projectile Launcher, see www.vernier.com/start/gdx-pl
 - For the Vernier Projectile Launcher, see www.vernier.com/start/vpl
4. Adjust the data-collection parameters to indicate you are using the Time of Flight Pad. You are now ready to collect data.

Using the Product

Using the Time of Flight Pad with a Projectile Launcher

Connect the Time of Flight Pad and projectile launcher following the steps in the Getting Started section of this user manual. Since the launcher does not automatically detect the Time of Flight Pad, it is necessary that you modify the data-collection settings to indicate that you are using the Time of Flight Pad.

Position the Time of Flight Pad so that the projectile will land near the center of the pad. Projectiles that land near the edges of the pad may not be detected. Start data collection and launch the projectile.

Compare the reported time of flight to the expected value calculated using elementary kinematics. To make this calculation, you will need to know the launch velocity, angle and speed, as well as the height difference between the projectile's initial launch height and the height of the surface of the Time of Flight Pad. The top surface of the Time of Flight Pad is 2.7 cm above the bottom surface.

Using the Time of Flight Pad as a standalone sensor connected to an interface

The Time of Flight Pad can be connected to a supported interface. Follow these steps to get connected:

- Connect the included photogate cable to the Time of Flight Pad.
- Connect the other end of the cable to the digital port of a supported interface.
- For platform and interface-specific connection instructions, see www.vernier.com/start/tof-vpl
- Adjust the photogate settings as needed to match the experiment you are doing.

The Time of Flight Pad identifies as a photogate and can be used in timing experiments that utilize time between gates or pulse timing modes. Most often you would use the Time of Flight Pad with a photogate to measure the time from passing through the photogate until the Time of Flight Pad is struck.

Using the Time of Flight Pad daisy-chained to a Vernier Photogate

Whenever possible, use the Time of Flight Pad connected directly to a supported interface. If your interface does not have an available digital port, you can daisy-chain the Time of Flight Pad to a photogate that is already connected to the interface. Follow these steps to get connected:

1. Connect the included photogate cable to the Time of Flight Pad.
2. Connect the other end of the cable to the daisy-chain port on a Vernier Photogate.
3. Connect the Vernier Photogate to the digital port of a supported interface.
4. For platform and interface-specific connection instructions for the photogate, see www.vernier.com/start/vpg-btd
5. Adjust the photogate settings as needed to match the experiment you are doing.

The Time of Flight Pad data will come in the same column as the daisy-chained photogate. This configuration can utilize time between gates or pulse timing modes. Most often you would use the Time of Flight Pad with a photogate to measure the time from passing through the photogate until the Time of Flight Pad is struck.

Using the Time of Flight Pad daisy-chained to Vernier Go Direct Photogate

You would use the Time of Flight Pad with Go Direct Photogate to replicate projectile experiments without the need for a projectile launcher. This configuration requires the Go Direct Time of Flight Pad cable (TOF-CB-GDX). This cable is sold separately and does not come with either the Go Direct Photogate or the Time of Flight Pad.

Follow these instructions to get connected:

1. Connect the Go Direct Time of Flight Pad cable to the Time of Flight Pad.
2. Connect the other end of the cable to the daisy-chain port on the Go Direct Photogate.
3. For platform-specific instructions for connecting Go Direct Photogate, see www.vernier.com/start/gdx-vpg
4. Adjust the selected sensor channels so that both the Object Velocity and Gate 1/Remote Gate – Timing channels are active.

Position Go Direct Photogate so that the projectile will pass through Go Direct Photogate's Gate 1 before Gate 2 as it is launched. This will ensure the projectile speed is reported as a positive value and that the correct value for time of flight is reported.

Safety

When using the Time of Flight Pad with a projectile launcher, we recommend students and instructors wear goggles at all times, including anyone in the vicinity of the projectile launch and landing areas.

The launching system of the projectile launcher requires simultaneous engagement of the “Arm” and “Launch” buttons to prevent accidental launches. Do not attempt to override or disable this feature.

Other safety considerations

- Do not put your face, hands, or other body parts near the end of the launch chamber while launching.
- Do not aim the launcher at a person or animal.

- Only apply pressure to the launcher using the pump provided.
- Do not exceed 150 psi when pressurizing the launch chamber.

Care and Maintenance

Do not store the Time of Flight Pad with any object compressing the pad. This could damage the pad by making it unable to compress properly when struck by an object during normal use.

How the Product Works

The Time of Flight Pad functions as an electrical switch to provide timing information. When a projectile strikes the surface of the Time of Flight Pad, a circuit is closed and that action is recorded by the software as a blocking event.

The Time of Flight Pad uses a timer to subsequently report an unblocking event about one second after the pad is struck. This time does not depend on how long the pad is compressed.

Sample Experiments

Here are a couple of additional experiments you can do using the Time of Flight Pad with a projectile launcher.

Constant Time of Flight for a Horizontally Projected Object

Set the Projectile Launcher to fire horizontally. How will the time to strike the floor vary with launch speed? Collect time of flight data for various launch speeds. Collect multiple trials for each speed to estimate the variations in the measurements.

Use Launch Angle and Speed to Predict Landing Position

Set the Projectile Launcher to a convenient launch angle. Fire and capture the projectile before it hits the floor in order to determine the launch speed. From the launch speed and angle, as well as the height of the launch point above the Time of Flight Pad surface, calculate where the projectile will land. Place the Time of Flight Pad in this location. Predict the time of flight for the projectile. Finally, fire the projectile, allowing it to fly to the Time of Flight Pad for the first time. Compare the measured time of flight and actual landing position to your predictions. Repeat for additional launch speeds and angles.

Troubleshooting

For troubleshooting and FAQs, see www.vernier.com/til/3300

Repair Information

If you have followed the troubleshooting steps and are still having trouble with your Time of Flight Pad, contact Vernier Technical Support at support@vernier.com or call 888-837-6437. Support specialists will work with you to determine if the unit needs to be sent in for repair. At that time, a Return Merchandise Authorization (RMA) number will be issued and instructions will be communicated on how to return the unit for repair.


Accessories/Replacements

Item	Order Code
Go Direct Projectile Launcher	GDX-PL
Vernier Projectile Launcher	VPL
Projectile Stop	PS-VPL
Photogate Cable	PG-BTD
Digital Extension Cable	EXT-BTD
Go Direct Time of Flight Pad Cable	TOF-CB-GDX

Note: For use with a Go Direct Photogate only

Warranty

Vernier warrants this product to be free from defects in materials and workmanship for a period of five years from the date of shipment to the customer. This warranty does not cover damage to the product caused by abuse or improper use.



Vernier Software & Technology
13979 SW Millikan Way • Beaverton, OR 97005-2886
Toll Free (888) 837-6437 • (503) 277-2299 • Fax (503) 277-2440
info@vernier.com • www.vernier.com

Rev. 10/15/2019

Go Direct and other marks shown are our trademarks or registered trademarks in the United States.

All other marks not owned by us that appear herein are the property of their respective owners, who may or may not be affiliated with, connected to, or sponsored by us.